COOKTOP PARTS

For Model: WERE3000PQ3
(White)

30" ELECTRIC FREESTANDING
STANDARD CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9761042	Use & Care Guide
	9756848	Installation Instructions
	9757895	Tech Sheet Template, Anti−Tip
	9757143	English/French
	9757142	English/Spanish
2		Bowl, Drip
	3196202	6" Black (2)
	3196203	8" Black (2)
3	3186231	Cooktop
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw
6	308605	Strain Relief
7	3195812	Rod, Support (2)
8	3195917	Clip, Spring
9	814399	Receptacle, Elmnt
10	3196154	Screw
11		Element, Surface
	8053266	6" (2)
	8053268	8"(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: WERE3000PQ3
(White)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	3186190	Left Hand
	3186191	Right Hand
2		Support, Endcap
	8523408	Left Hand
	8523409	Right Hand
3	9758903	Panel, Backguard
4		Switch, Infinite
	3148954	Left Front
	3148952	Left Rear
	3148954	Right Rear
	3148952	Right Front
	3400882	Screw (8)
5	8523265	Light, Indicator
6	3196068	Lens, Light
7	8522565	Knob, Infinite (4)
8	8053912	Shield, Heat
9	4449746	Screw
10	8272473	Cover, Upper
11	3149360	Switch, Rocker
12	6610463	Control, Range
13	3196178	Screw
14	9758283	Cover, Box
15	8273564	Clip
16	3400882	Screw
17	3196200	Clip, Spring (2)
18	9780585	Wire Guard
19	9757601	Breaker, 15amp
20	9758885	Outlet, Untimed

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: WERE3000PQ3
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: WERE3000PQ3
(White)

Illus. No.	Part No.	DESCRIPTION
1	3169143	Vent Tube
2	3186144	Box, Burner
3	8053830	Panel, Side (2)
4	3196548	Fuse, Thermal
5	3186152	Seal, Oven Door
6	9757340	Element, Broil
7	9758541	Element, Bake
8	9758701	Spacer, Door
10	3195546	Glide, Drawer Frnt
11	3196037	Foot, Front (2)
12	9758224	Frame, Front
13	8054068	Tray, Insulation
14	3196576	Clip, Panel (6)
15	9760314	Rail, Base (2)
16	9761935	Foot, Rear (2)
18	3195809	Bumper, Side (2)
19	3186116	Support, Oven (2)
20	3186034	Bracket, Service
21	4449868	Block, Terminal
	112432	Nut (3)
22	8274034	Back, Main
23	9758161	Switch, Door
24	3196701	Light Socket Assy
25	311255	Bulb, Oven Light
26	9757239	Rod − Dr Switch
27	8273902	Sensor, Oven
28	3196165	Screw
29	3196179	Screw
30	3196178	Screw
31	3400016	Screw
32	3196176	Screw
33	3196169	Screw
34	3196177	Screw
35	3196567	Screw
36	3196168	Screw
37	3196174	Screw
38	3196172	Screw

INSULATION

	8272616	Insulation, Wrap
	8272611	Insulation, Back

DRAWER & BROILER PARTS

For Model: WERE3000PQ3
(White)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272606	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6	3196814	Rivet, Push (2)
7	8053339	Panel, Drawer Frnt
9	8053334	Glide, Drawer (2)
10	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: WERE3000PQ3
(White)



Illus. No.	Part No.	DESCRIPTION
1	8522433	Trim, Top
2	3196164	Screw
3	8522444	Handle, Door
4	3186292	Liner, Door
6	9758162	Window, Inner
7	9759622	Retainer, Insul.
8	8053808	Hinge, Door (2)
9	8053480	Glass, Outer
10		Trim, Side
	8523172	Left Hand
	8523166	Right Hand
11	3196160	Screw
12	8523175	Trim, Lower
15	3196161	Screw
17	3196025	Clip, Glass (6)
21	3196925	Clip, Door Stop
22	3196165	Screw

OPTIONAL PARTS

For Model: WERE3000PQ3
(White)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3184478	Cleaner, Glass

ANTI−TIP KIT

9757976	Anti−Tip Kit

WIRING HARNESS PARTS

3196793	Harness, Wire (Cooktop)
9758197	Harness, Wire (EZ175)
311227	Wire, Ground
3196154	Screw
9756752	Harness, Wire (Sensor)
9756350	Cord, Power
9756779	Relief, Strain
3196173	Screw, Ground
3196174	Screw (Grnd / Main Back)

Miscellaneous

3196897	Pin Kit−Dr Removal